



## Remote Control Instructions

### **How to Connect Your Remote to your Gate Opener**

- A. Open the gate opener hood, and lift the panel to find the circuit board.
- B. On the circuit board, look for the word "STUDY", generally located in the middle left side.
- C. Press and hold the button on the remote control.
- D. Press and hold the STUDY button on the circuit board for 1.5-2 seconds.
- G. You are now finished. The remote is now connected to the gate opener.

If that didn't work, it's because the STUDY key was probably held down for too long. 1.5 to 2 seconds generally works.

### **Removing existing remotes**

Press the STUDY key and hold for 8 seconds, watching light state: flashing-solid-flashing, the removal is done. All existing Self-study codes have been removed.

### **Video Instructions**

Visit the link below to watch a video on how to connect your remote to your gate opener.

<https://www.youtube.com/watch?v=QfT6O4apTI8>