Adjusting the Photo Eye

If the gate is having trouble closing, it could be that the photo eye wasn't set up properly, or the orange button was left on. Follow these steps to reset your photo eye.

1. Open the hood of your gate opener and press the reset button on the gate operator circuit board.

2. Press the orange button on the photo eye to turn on the infrared beam. Figure 1
   You should see a red light hit the reflector. Make sure the red light is inside the circle. Figure 2

Infrared beam
inside circle

Figure 1   Figure 2

3. Press the orange button on the photo eye to turn off the infrared beam. Important, make sure this light remains off!

Note: Make sure nothing is blocking the photo eye. Things such as trees, bushes, or other objects blocking the photo eye will cause the gate to not close properly.

Youtube
Youtube video with more details on how to install the photo eye: https://youtu.be/F7NpB9W_OMY