

CALIMET CM9-509 REMOTE (RED) INSTRUCTIONS



Connecting your remote control to your gate opener

Numeric mode is an encrypted, more secure connection.

- A. Open the hood of your gate opener, and lift the panel to find the circuit board.
- B. On the gate operator circuit board, look for the words OFF <-> ON (generally on the left side), and flip the switch to ON.
- C. Use a screwdriver to unscrew the back of your new remote control.
- D. On the back of the remote control are 1-8 dip switches. Each switch can be moved in three positions: +, 0, or -. Set these switches to any random position of your choice.
- E. On the gate operator circuit board, look for the 1-8 dip switches, generally located on the left side of the circuit board. Set the same positions of the 1-8 dip switches as you did on the remote control in the previous step.
- F. Finished

Video Instructions

Visit the link below to watch a video on how to connect your remote to your gate opener.

<https://www.youtube.com/watch?v=QfT6O4apTI8>